

**NEVER LEAVE HEATER
UNATTENDED WHILE BURN-
ING OR WHILE CONNECTED
TO A FUEL SOURCE**



**Propane
Tank Top Heaters**

Exploded View




Figure 4. Exploded view of Heater

Replacement Parts List

Item Number	Description	Part Number for Models:			
		PT-15-TT	PT-15-TT-P	PT-30TT	PT-30-TT-P
1	Regulator Assembly	20-032-0001	20-032-0001	20-032-0002	20-032-0002
2	Hose Assembly	-	-	20-051-0001	20-051-0001
3	Manifold Assembly	-	-	20-111-0001	20-111-0001
4	Safety Valve Assembly	20-013-0001	20-013-0001	20-013-0001	20-013-0001
5	Burner Assembly	20-023-0001	20-023-0002	20-023-0001	20-023-0002
6	Front Guard	20-101-0001	20-101-0001	20-101-0001	20-101-0001
7	Thermocouple	20-091-0001	20-091-0001	20-091-0001	20-091-0001
8	Tank Collar Bracket	-	-	20-504-0001	20-504-0001
9	Mounting Bolt Knob	-	-	20-503-0001	20-503-0001
10	Piezo Light	-	20-122-0001	-	20-122-0002
11	Rear Guard	20-101-0002	20-101-0002	20-101-0002	20-101-0002

Pinnacle Products International, Inc. reserves the right to make any changes in materials, specifications, prices or design without notice. Pinnacle Products International, Inc. may also discontinue items at any time.